



WONDER CUPS INSTALLATION

THIS KIT INCLUDES: 2 X DMR WONDER CUPS, 3 X M4 X 60MM BOLTS

IF YOU ARE UNSURE HOW TO FIT THIS PRODUCT OR IF YOU DO NOT HAVE THE CORRECT TOOLS - ASK YOUR DEALER TO FIT IT FOR YOU.

- A: Press the cup with the right hand thread & 3 threaded holes into the 'non - drive' side of the BB shell.
- B: Place the M4 x 60mm bolts in the other cup & line it up with the threaded holes in the installed cup.
- C: Slowly tighten each bolt until it starts to 'pull in' the cup a little bit.
- D: Once the cup is pulled in a little bit, remove the 3 bolts & press in the cup fully.
- E: Ensure that the bolts & threaded holes line up correctly. If they do not you will have to remove the cup & repeat steps; B, C & D.
- F: Fit the bolts & fully tighten
- G: Install a 73mm cartridge type BB

⚠️ Regularly inspect or have your dealer inspect your cycle ⚠️