



e.thirteen

SRS SET UP TIPS for 2002/2003 GIANT DH Frame

The instructions are very accurate and if you follow them closely there should be no problem with the set up.

Follow Instructions for frames WITHOUT International Standard Chainguide Tabs

Follow Instructions until Step 3:

Fit up the IMCS mount flange to your frame. Since the Giant has over a 125 mm spindle and the IMCS does not fit properly on the Giant bottom bracket due the pre-existing chainguide mount and linkage you will use the IMCS mount flange with the **cupped side facing away** from the bottom bracket. Use your flanged fixed cup type bottom bracket to sandwich the IMCS mount flange against the flat face of the bottom bracket shell. The open side of the flange should be facing the 10 o'clock position. See Fig 3 for approximate IMCS mount flange orientation.

Then follow Instructions step 4- 7:

Where you will Mount the entire slider/back plate assembly to the IMCS mount flange using the on of the 2 sets of three equal length M6 flathead screws. The two lengths of screws that are included with your chainguide are for use with the appropriate number of washers. **(We have found that 1 works best but could potentially rub, While I have seen others use no spacers.)**

Then Follow Instructions 8- 10:

If you have any more questions feel e.thirteen Product Support at:

support@e13components.com
Phone at 207 846 3355